Hose Type 13/2WM

ID13 - Series: M



Applications

Hydraulics:	Hydraulic tools (instrumentation packages for gauges, control of service equipment, hydraulic jacks, hydraulic tools)
Oil and Gas:	Methanol service (oil rigs, distribution panels, umbilicals), jumper/ subsea well control, control of subsea hydraulic components, nitrogen service



Technical Information

Inner Core:	BESNO P40 TLO (PATT)
Pressure Support:	2 open layers, 2 dense layers of high-tensile steel wire
Outer Cover:	Polyamide (PA)
Colour:	Dark blue
Temperature:	-30°C to +60°C [-22°F to 140°F]

ØID	Ø OD	Working	Pressure	Burst Pressure	Bend Radius	Weight	Insert ID
		(SF 2,5:1)	(SF 4,0:1)				
12,7 mm	20,8 mm	1.100 bar	690 bar	2.760 bar	150 mm	0,630 kg/m	8,5 mm
0,50 inch	0,82 inch	16.000 psi	10.000 psi	40.000 psi	5,91 inch	0,422 lbs/ft	0,33 inch

	Dim	ensions	(mm)	Sleeve			
Part no.	Thread	Material	А	В	С	Y	JIEEVE
Sleeve							
11330181W	-	Steel	27,8	60	-	-	
11330185W	-	AISI 316Ti	27,8	64	-	-	≪B

Part no.	Thread	Material	Nut	L A		nsions (r B	nm) C	압 암	Insert
Male fitting									
31320401M	I/2"x14NPT	Steel	-	8,	,5	104	18	22	
Type M femal 21320645M	I"x12UNF	AISI 316Ti	51360645	8,	,5	86	-	32	

 JIC female swivel

 21320615M
 3/4"x16UNF
 AISI 316Ti
 51320615
 8,5
 79
 24



Hose Type 13/2WM



ID13 - Series: M

Part no.	Thread		Material Relief b		res	Dime A	ensions (B	(mm) C	e e	Swivel nut
Swivel nu	t									
51320615	3/4"×1	6UNF	AISI 316Ti	l radial		14,2	22,5	17,5	24	t → L L L L L L L L L L L L L
51360645	"x12	UNF	AISI 316Ti	l radial		16,8	28	22	32	
Part no.	Mesh length (mm)	Overall len (mm)	gth Breaking (kN)	g strength	Suitable for SPIR STAR® ho outer diameter (mm)	ose				Hose securing grip
Hose secu	uring grip shou	rt version								
9106400	600,00	800,00	20,40		20-25					665555555555555555

Production-related variations of the burst pressure of up to 5 % are possible. Other colours upon request.

The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center.

The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly may be less.

*) Blast-Pro® fittings may only be used for tube cleaning operations inside the tube. They have not been designed for the use outside of tubes.

We reserve our rights for technical changes without notice. Subject to printing errors.

